

Environmental Testing Laboratory

6/15/2016

Dale Giovannetti
Central Point Sch. Dist/Sams Valley Elem
300 Ash St.

Central Point, OR 97502

TEL: (541) 973-3222

FAX

RE: Patrick Elementary

Dear Dale Giovannetti:

Neilson Research Corporation received 3 sample(s) on 6/2/2016 for the analyses presented in the following report.

Order No.: 1606077

The results relate only to the parameters tested or to the sample as received by the laboratory. This report shall not be reproduced except in full, without the written approval of Neilson Research Corporation. If you have any questions regarding these test results, please feel free to call.

Sincerely,

Neilson Research Corporation

Alec C Smith

Project Manager

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report

ORELAP 100016 EPA OR00028

CLIENT: Central Point Sch. Dist/Sams Valley Elem

Project: Patrick Elementary

Lab Order: 1606077

CASE NARRATIVE

Date: 15-Jun-16

The analyses were performed according to the guidelines in the Neilson Research Corporation Quality Assurance Program. This report contains analytical results for the sample(s) as received by the laboratory.

Neilson Research Corporation certifies that this report is in compliance with the requirements of NELAP. No unusual difficulties were experienced during analysis of this batch except as noted below or qualified with data flags on the reports.

The lead action level for schools is 0.02 mg/L.

Page 1 of 1

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report ORELAP 100016
EPA 0R00028

Central Point Sch. Dist/Sams Valley Ele Lab Order: 1606077
300 Ash St. NRC Sample ID: 1606077-01A

Central Point, OR 97502 Collection Date: 6/2/2016 7:18:00 AM

Received Date: 6/2/2016 10:07:00 AM

Reported Date: 6/15/2016 3:23:41 PM

Sample Information:

Client Sample ID: Bottle #14945

Patrick Elementary Collectors Name: Dale Giovannetti

Sample Location: Staff Breakroom

Source: City Water

ANALYTICAL RESULTS

Analyses	Method	NELAI Accredit	ed Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	EPA 200.8	А	0.00198		0.000515	mg/L	1.3 AL	6/8/2016	BAR
Lead	EPA 200.8	Α	0.00138		0.000103	mg/L	0.015 AL	6/8/2016	BAR

Notes: ND - Not Detected at the MRL N.L. - No Limit

MRL - Minimum Reporting Limit

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report ORELAP 100016
EPA OR00028

Central Point Sch. Dist/Sams Valley Ele Lab Order: 1606077
300 Ash St. NRC Sample ID: 1606077-02A

Central Point, OR 97502 Collection Date: 6/2/2016 7:33:00 AM

Received Date: 6/2/2016 10:07:00 AM Reported Date: 6/15/2016 3:23:41 PM

Sample Information:

Client Sample ID: Bottle #16608

Patrick Elementary Collectors Name: Dale Giovannetti

Sample Location: Gym Drinking Fountain

Source: City Water

ANALYTICAL RESULTS

Analyses	Method	NELAP Accredited	l Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	EPA 200.8	А	0.0749		0.000515	mg/L	1.3 AL	6/8/2016	BAR
Lead	EPA 200.8	Α	0.000106		0.000103	mg/L	0.015 AL	6/8/2016	BAR

Notes: ND - Not Detected at the MRL

N.L. - No Limit

MRL - Minimum Reporting Limit

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report ORELAP 100016
EPA 0R00028

Central Point Sch. Dist/Sams Valley Ele Lab Order: 1606077
300 Ash St. NRC Sample ID: 1606077-03A

Central Point, OR 97502 Collection Date: 6/2/2016 7:27:00 AM

Received Date: 6/2/2016 10:07:00 AM Reported Date: 6/15/2016 3:23:41 PM

Sample Information:

Client Sample ID: Bottle #14925

Patrick Elementary Collectors Name: Dale Giovannetti

Sample Location: Playground Drinking Fountain

Source: City Water

ANALYTICAL RESULTS

Analyses	Method	NELAP Accredited	l Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	EPA 200.8	А	0.0626		0.000515	mg/L	1.3 AL	6/8/2016	BAR
Lead	EPA 200.8	Α	0.000488		0.000103	mg/L	0.015 AL	6/8/2016	BAR

Notes: ND - Not Detected at the MRL

N.L. - No Limit

MRL - Minimum Reporting Limit

Date: 15-Jun-16

CLIENT: Central Point Sch. Dist/Sams Valley Elem

Work Order: 1606077

Project: Patrick Elementary

ANALYTICAL QC SUMMARY REPORT

TestCode: ICPMS_200.8_DW

Sample ID	MB-35363	SampType: MBLK	TestCoo	de: ICPMS_20	00.8 Units: mg/L		Prep Dat	e: 6/6/20 1	16	RunNo: 877	719	
Client ID:	ZZZZZ	Batch ID: 35363	TestN	lo: EPA 200. 8	B (EPA 200.8)		Analysis Dat	e: 6/8/20 1	16	SeqNo: 130	08157	
Analyte		Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual
Copper Lead		ND ND	0.000515 0.000103									
Sample ID	LCS-35363	SampType: LCS	TestCod	de: ICPMS_2	00.8 Units: mg/L		Prep Dat	e: 6/6/20 1	16	RunNo: 877	719	
Client ID:	ZZZZZ	Batch ID: 35363	TestN	lo: EPA 200. 8	B (EPA 200.8)		Analysis Dat	e: 6/8/20 1	16	SeqNo: 130	08158	
Analyte		Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual
Copper Lead		0.09441 0.09910	0.000520 0.000104	0.1 0.1	0 0	94.4 99.1	85 85	115 115				
Sample ID	1606078-03AMS	SampType: MS	TestCoo	de: ICPMS_2	00.8 Units: mg/L		Prep Dat	e: 6/6/20 1	16	RunNo: 877	719	
Sample ID Client ID:		SampType: MS Batch ID: 35363		de: ICPMS_20	•		Prep Dat Analysis Dat			RunNo: 87 7 SeqNo: 13 0		
·				lo: EPA 200. 8	•	%REC	Analysis Dat	e: 6/8/20 1				Qual
Client ID:		Batch ID: 35363	TestN	lo: EPA 200. 8	B (EPA 200.8)		Analysis Dat	e: 6/8/20 1	16	SeqNo: 130	08182	Qual
Client ID:		Batch ID: 35363 Result	TestN MRL	No: EPA 200. 8	SPK Ref Val	%REC	Analysis Dat	e: 6/8/201 HighLimit	16	SeqNo: 130	08182	Qual
Client ID: Analyte Copper Lead		Batch ID: 35363 Result 0.1267	TestN MRL 0.000520 0.000104	SPK value 0.1 0.1	SPK Ref Val 0.03877	%REC 87.9	Analysis Date LowLimit 70 70	e: 6/8/20 1 HighLimit	RPD Ref Val	SeqNo: 130	08182 RPDLimit	Qual
Client ID: Analyte Copper Lead	2ZZZZ 1606078-03AMSD	Batch ID: 35363 Result 0.1267 0.09753	MRL 0.000520 0.000104 TestCoo	SPK value 0.1 0.1	SPK Ref Val 0.03877 0.001822 00.8 Units: mg/L	%REC 87.9 95.7	Analysis Date LowLimit 70 70	HighLimit 130 130 e: 6/6/201	RPD Ref Val	SeqNo: 130 %RPD	RPDLimit	Qual
Client ID: Analyte Copper Lead Sample ID	2ZZZZ 1606078-03AMSD	Batch ID: 35363 Result 0.1267 0.09753 SampType: MSD	MRL 0.000520 0.000104 TestCoo	O.1 0.1 de: ICPMS_20	SPK Ref Val 0.03877 0.001822 00.8 Units: mg/L	%REC 87.9 95.7	Analysis Date LowLimit 70 70 Prep Date Analysis Date	HighLimit 130 130 e: 6/6/201 e: 6/8/201	RPD Ref Val	SeqNo: 130 %RPD RunNo: 877	RPDLimit	Qual
Client ID: Analyte Copper Lead Sample ID Client ID:	2ZZZZ 1606078-03AMSD	Batch ID: 35363 Result 0.1267 0.09753 SampType: MSD Batch ID: 35363	MRL 0.000520 0.000104 TestCoo	O.1 0.1 de: ICPMS_20	SPK Ref Val 0.03877 0.001822 00.8 Units: mg/L (EPA 200.8)	%REC 87.9 95.7	Analysis Date LowLimit 70 70 Prep Date Analysis Date	HighLimit 130 130 e: 6/6/201 e: 6/8/201	RPD Ref Val	SeqNo: 130 %RPD RunNo: 877 SeqNo: 130	08182 RPDLimit 719 08183	

Qualifiers: E Value above quantitation range

ND Not Detected at the Minimum Reporting Limit

H Holding times for preparation or analysis exceeded

R RPD outside accepted recovery limits

J Analyte detected below quantitation limits

S Spike Recovery outside accepted recovery limits



LAB	NRC Sample Number: \(CoO(oOT) - O\A	Date Received: 6,2,116
	Received By: \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	Time Received: 10: am/pm

Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your State under the Lead and Copper Rule, and is being accomplished through collaboration between the public water system and their consumers (e.g. residents).

Collect samples from a tap that has not been used for at least 6 hours. To ensure the water has not been used for at least 6 hours, the best time to collect samples is either early in the morning or in the evening upon returning from work. Be sure to use a kitchen or bathroom cold water tap that has been used for drinking water consumption in the past few weeks. The collection procedure is described below.

- Prior arrangements will be made with you to coordinate the sample collection. Dates will be set for sample kit delivery and pick-up by water system staff.
- 2. There must be a minimum of 6 hours during which there is no water used from the tap where the sample will be collected and any taps adjacent or close to that tap. Either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist. Do not intentionally flush the water line before the start of the 6 hour period.
- 3. Use a kitchen or bathroom cold-water faucet for sampling. If you have water softeners on your kitchen taps, collect your sample from the bathroom tap that is not attached to a water softener, or a point of use filter, if possible. Do not remove the aerator prior to sampling. Place the opened sample bottle below the faucet and open the cold water tap as you would do to fill a glass of water. Fill the sample bottle to the line marked 1000-mL" and turnoff the water.
- Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
- 5. If any plumbing repairs or replacements have been done in the home since the previous sampling event, note this information on the back of this form. Also if your sample was collected from a tap with a water softener, note this as well.
 - 6. Place the sample kit in the location the kit was delivered to so that water system staff may pick up the sample kit.
- 7. Results from this monitoring effort and information about lead will be provided to you as soon as practical but no later than 30 days after the system learns of the tap monitoring results. However, if excessive lead and/or copper levels are found, immediate notification will be provided (usually 1-2 working days after the system learns of the tap monitoring results).

Call	at	if you have any questions.
	TO BE COMPLETED BY RESIDE	NT
Water was last used:	Time 3:00 : PM am/pm	Date 1 1 12016
Sample was collected:	Time 7!18 : 6 m am/pm	Date (12 12016
Name of Water System:	atrick Elementory	PWS ID 41
Sample Collected by:	Dala Giovannetti	Bottle # 14945
Address: 1500 2	nd Ave. Gold Hill	_Ove, Space #
Faucet Location: (e.g. Kitch	nen Faucet) Staff Brewk	room
I have read the ab	ove directions and have taken a tap sample	in accordance with these directions.
Signature	Page 7 of 9	ate <u>G-2-16</u>



NEILSON RESEARCH CORPORATION

LAB	NRC Sample Number: 160607-03A Received By: 11006000000000000000000000000000000000	Date Received: 10:07 (am/pm
	Tan Campl	Collection Procedures

Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your State under the Lead and Copper Rule, and is being accomplished through collaboration between the public water system and their consumers (e.g. residents).

Collect samples from a tap that has not been used for at least 6 hours. To ensure the water has not been used for at least 6 hours, the best time to collect samples is either early in the morning or in the evening upon returning from work. Be sure to use a kitchen or bathroom cold water tap that has been used for drinking water consumption in the past few weeks. The collection procedure is described below.

- 1. Prior arrangements will be made with you to coordinate the sample collection. Dates will be set for sample kit delivery and pick-up by water system staff.
- 2. There must be a minimum of 6 hours during which there is no water used from the tap where the sample will be collected and any taps adjacent or close to that tap. Either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist. Do not intentionally flush the water line before the start of the 6 hour period.
- 3. Use a kitchen or bathroom cold-water faucet for sampling. If you have water softeners on your kitchen taps, collect your sample from the bathroom tap that is not attached to a water softener, or a point of use filter, if possible. Do not remove the aerator prior to sampling. Place the opened sample bottle below the faucet and open the cold water tap as you would do to fill a glass of water. Fill the sample bottle to the line marked "1000-mL" and turnoff the water.
- 4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
- 5. If any plumbing repairs or replacements have been done in the home since the previous sampling event, note this information on the back of this form. Also if your sample was collected from a tap with a water softener, note this as well.
 - 6. Place the sample kit in the location the kit was delivered to so that water system staff may pick up the sample kit.
- 7. Results from this monitoring effort and information about lead will be provided to you as soon as practical but no later than 30 days after the system learns of the tap monitoring results. However, if excessive lead and/or copper levels are found, immediate notification will be provided (usually 1-2 working days after the system learns of the tap monitoring results).

nounou.	Call	at		if you	have any questions.	
		TO BE COMPLETE		Γ	1 1 . 2016	
	Water was last used:	Time	Londo	Date	611 12016	
	Sample was collected:	Time_7' : 33	-	Date	6 12 10016	
	Name of Water System:	atrick Elen	entary	_	PWS ID 41	
	Sample Collected by:	Pale Gjovan	ne#1		Bottle # 10008	
	Address: 1500 21	a) Ave Gold	1711 0	KR.	Space #	
	Faucet Location: (e.g. Kitch	en Faucet) 6 x m]	Drinkin.	& For	tasn	
	I have read the ab	ove directions and have tak	en a tap sample	in accorda	ance with these directions.	
	Signature	Page 8	D	ate 6	2-2016	



LAB	NRC Sample Number: \(\(\chi(\chi(\chi(\chi(\chi(\chi(\chi(\	Date Received: 017 16
	Received By: \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	Time Received: : : (am/pm

Directions for Homeowner Tap Sample Collection Procedures

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your State under the Lead and Copper Rule, and is being accomplished through collaboration between the public water system and their consumers (e.g. residents).

Collect samples from a tap that has not been used for at least 6 hours. To ensure the water has not been used for at least 6 hours, the best time to collect samples is either early in the morning or in the evening upon returning from work. Be sure to use a kitchen or bathroom cold water tap that has been used for drinking water consumption in the past few weeks. The collection procedure is described below.

- Prior arrangements will be made with you to coordinate the sample collection. Dates will be set for sample kit delivery and pick-up by water system staff.
- 2. There must be a minimum of 6 hours during which there is no water used from the tap where the sample will be collected and any taps adjacent or close to that tap. Either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist. Do not intentionally flush the water line before the start of the 6 hour period.
- 3. Use a kitchen or bathroom cold-water faucet for sampling. If you have water softeners on your kitchen taps, collect your sample from the bathroom tap that is not attached to a water softener, or a point of use filter, if possible. Do not remove the aerator prior to sampling. Place the opened sample bottle below the faucet and open the cold water tap as you would do to fill a glass of water. Fill the sample bottle to the line marked 1000-mL" and turnoff the water.
- Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
- 5. If any plumbing repairs or replacements have been done in the home since the previous sampling event, note this information on the back of this form. Also if your sample was collected from a tap with a water softener, note this as well.
 - 6. Place the sample kit in the location the kit was delivered to so that water system staff may pick up the sample kit.
- 7. Results from this monitoring effort and information about lead will be provided to you as soon as practical but no later than 30 days after the system learns of the tap monitoring results. However, if excessive lead and/or copper levels are found, immediate notification will be provided (usually 1-2 working days after the system learns of the tap monitoring results).

		-				
Call	at	if you have any questions.				
	TO BE COMPLETED BY RESIDE	NT				
Water was last used:	Time 3:00: p am/pm	Date 6 1 1 12016				
Sample was collected:	Time 7:27 : 6 M @ m/pm	Date 6 12 12016				
Name of Water System:	atrick Elementary	PWS ID 41				
Sample Collected by:	Dale Grovannetti)	Bottle # 14025				
Address: 1500	and Ave. Gold Hi	ll ove. Space #				
Faucet Location: (e.g. Kitch	en Faucet) Play Ground T	Winking Fountain				
	I have read the above directions and have taken a tap sample in accordance with these directions.					
Signature	4	late 6-2-2016				